

INSTALLATION MANUAL

18151

Level of Difficulty

Easy

Parts List

#	Qty	Description
1	2	Frame half
2	1	Shank, 2"
3	2	Connecting plate
4	1	Folding shank assembly
5	1	Clip
6	1	Pin, 5/8"
7	1	Lock nut, M16
8	1	Hex head bolt, M16*80
9	2	Lock nut, M12
10	2	Flat washer, M12
11	2	Hex bolt, M12*75
12	8	Lock nut, M10
13	8	Flat washer, M10
14	8	Carriage bolt, M10*20

Tools Required

Open wrench, 17mm	Open wrench, 24mm
Open wrench, 19mm	Adjustable wrench

⚠ WARNING

Do not exceed maximum weight capacity of 500 lbs. when using 2" receiver tube. Distribute the weight evenly on platform when hauling a load.
NOTE: This carrier is not intended for transporting people.

Do not carry loads wider or deeper than carrier. Do not carry flammable items on carrier. Do not allow exhaust fumes to blow directly on items. This is a fire hazard.

Product Photo



Notes and Maintenance

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To protect the product, wax after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For polished, gloss and other smooth finishes, polish may be used to clear small scratches and scuffs on the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

Product Registration

CURT Group stands behind our products with industry leading warranties. You can help us continue to improve our product line and help us understand your needs by registering your purchase by visiting:

warranty.curtgroup.com/surveys

At CURT Group, customer is king. We value your feedback and we use that information to make improvements on our products. Please, take a minute and let us know how we are doing.

ASSEMBLY

Step 1

Align the two platform halves (#1) on either side of the 2" shank (#2). Insert the two M12*75 carriage bolts (#11) through the frame (#1), shank (#2) and other frame half (#1). Install M12 flat washers (#10) and M12 locknuts (#9) on the bolts (#11). Snug the hardware, but do not fully tighten.

Step 2

Place the two connecting plates (#3) onto the front and back of the frames (#1). Insert the M10 bolts (#14) through the outside of the frames (#1) followed by the M10 flat washers (#13) and secure with M10 locknuts (#12) to the inside of the frames (#1).

Step 3

Tighten all hardware at this time.

Step 4

Connect the folding shank assembly (#4) to the shank (#2) with an M16*80 hex bolt (#8), pin (#6) and clip (#5).

Step 5

To adjust the cargo carrier to the upright, folded position, remove the pin and clip (#5, #6). Turn the frame body up until it is vertical. Insert the pin (#6) through the shank (#2) and the lower hole of the folding shank assembly (#4). Insert the clip (#5) into the pin #6).

Parts List

#	Qty	Description
1	2	Frame half
2	1	Shank, 2"
3	2	Connecting plate
4	1	Folding shank assembly
5	1	Clip
6	1	Pin, 5/8"
7	1	Lock nut, M16
8	1	Hex head bolt, M16*80
9	2	Lock nut, M12
10	2	Flat washer, M12
11	2	Hex bolt, M12*75
12	8	Lock nut, M10
13	8	Flat washer, M10
14	8	Carriage bolt, M10*20

