## INSTALLATION INSTRUCTIONS AND PARTS LIST

APPLICATION: 480752 STAINLESS STEEL SIDE ENTRY STEPS: 2007 AND NEWER TOYOTA TUNDRA DOUBLE CAB



- 1. Read Instructions completely and check to make sure that all required parts (listed on service parts list) are on hand before starting the installation.
- 2. The mounting brackets are attached to the step plate for your convenience. The *LUVERNE* decal is located on the front driver's side.
- 3. The step assemblies must be mounted to the inboard surface of the rocker panel per the following instructions.
  - 3.1. Position the step assembly (item #1 thru #14) up under the rocker panel so that the holes in the brackets line up with the holes on the inside of the rocker panel.
  - 3.2. Attach the brackets to the vehicle using M8-1.25 X 25MM screw, lock washer, and flat washer (items #15 #16 #17). Repeat for all brackets.
  - 3.3. Torque all screws to 19 lb. ft.

## SERVICE PARTS LIST

ITEM	PART NO.	QTY	DESCRIPTION
1	551366	1	STEP PLATE-SES,RH,TOY TUNDRA DBL CAB
2	551367	1	STEP PLATE-SES,LH,TOY TUNDRA DBL CAB
3	551362	2	BRKT-MTG, #1, TOY TUNDRA
4	551363	2	BRKT-MTG, #2, TOY TUNDRA
5	551364	2	BRKT-MTG, #3, TOY TUNDRA
6	551365	2	BRKT-MTG, #4, TOY TUNDRA
7	104250	2	END CAP-RH FRONT/LH REAR
8	104251	2	END CAP-LH FRONT/RH REAR
9	102600	4	PAD,STEP PLATE,20.00"
10	104255	2	TRIM-SEAL,SES,EXTRUDED, 80.5"
11	104257	12	NUT-HEX,SGL SELF THD,CAP WASHER,1/4"
12	104258	12	BOLT-CARRIAGE,SST,#10-24 X 3/4"LG
13	104259	4	BOLT-CARRIAGE,CLP HD,SST,#10-24 X 3/4"LG
14	104261	16	NUT-SERRATED FLANGE,HEX,SST,#10-24
15	102549	16	SCREW-HEX HD,M8-1.25 X 25MM
16	100030	16	WASHER-LOCK, 5/16"
17	100034	16	WASHER-FLAT, 5/16"
18	104530	16	WASHER-NEOPRENE, .200 X .468 X .03



REV A 02FEB08 551369 Sheet 1 30JAN07

