



X-CONTOUR™ FLOOR LINERS

PT #5527

CARE AND USE INSTRUCTIONS

Thank you for selecting an X-act Contour™ Floor Liner from Husky Liners. Your new rear floor liner is custom molded to fit your vehicle. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR REAR FLOOR LINER



TO EASE THE INSTALLATION OF YOUR REAR FLOOR LINER, FIRST MOVE BOTH FRONT SEATS COMPLETELY FORWARD. THEN, INSTALL YOUR LINER ORIENTED AS SHOWN ABOVE. ONCE YOU HAVE INSTALLED YOUR LINER, REPOSITION THE FRONT SEATS AS DESIRED.