

56141

NISSAN PATHFINDER

English

1. The vehicle's factory tow plug is located on the driver's side, along the frame rail behind the rear bumper (A). The connector will be similar to the one on the 4-Flat harness. Remove the protective cap, taking care not to damage the locking tabs.

2. Insert the 4-Flat harness connector into the vehicle's tow harness connector making sure that the locking tab is in place (B).

3. Route the 4-Flat to the center of the vehicle and secure in a convenient out of the way location.

4. Secure any loose wires using the cable ties provided.

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!


Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!


Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

8/10/2011

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-877-287-8634



A



B