



# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal (A).

## Step 2

Open the vehicle trunk. Remove all trunk floor coverings (B).

## Step 3

Remove all the cargo tie downs and push fasteners from both sides of the trunk liner (C).

## Step 4

Remove the scuff panel by pulling out on the bottom and then up (D).

## Step 5

Pull back on the felt liner behind the driver side tail light to locate the vehicle taillight wiring harness connectors (H). The connectors will be similar to those on the T-connector harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (E).

## Step 6

Insert the T-connector end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 7

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

## Step 8

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

## Step 9

Route the T-connector end with the green wire to the passenger side behind the removed scuff panels. Repeat Steps 6 and 7 on the passenger side using the T-connector end with the green wire.

## Step 10

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the double-sided tape provided (F).

## Step 11

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

## Step 12

Reinstall all items removed during install and reconnect the negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

