



**RAM 3500 DUALY
WITHOUT FENDER FLARES**

REAR MUD GUARD INSTALLATION INSTRUCTIONS

Please read instructions thoroughly before installation.

Tools Required

- 8mm Socket / Driver

Package Contents

- Rear Mud Guard Set
- Spring Clips X 2
- Instruction Sheet

Determine which mudguard you have by locating the part number molded in the mounting flange (5908 DS and 5908 PS).

1. Clean and degrease the mud guard mounting location area on the fender before installation.
2. Remove existing fasteners from locations A and B using 8 mm socket
3. Peel red protective cover from the 3M adhesive on the mudguard.
4. Attach mud guard to rear fender with factory fasteners at locations A and B, check fit and make sure mud guard is parallel to ground before tightening. Be sure to press firmly on the area with the 3M adhesive tape to make sure adhesive is set.
5. Install spring clips where shown. Clips will go behind the metal fender and over the mud guard, securing it in place.

