

2500/3500 HD GMC Sierra

REAR MUD GUARD INSTALLATION INSTRUCTIONS*Install Paint Protection Film before mud guards (see other side)**Please read instructions thoroughly before installation.***Tools Required**

- T20 Torx

Package Contents

- Driver and Passenger Side Rear Mud Guards
- Spring Clips (Qty 2)
- Instruction Sheet

Determine which mudguard you have by locating the part number molded in the mounting flange (5929 DS and 5929 PS).

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fasteners from locations A, B, and C.
3. Attach mud guard to rear fender with factory fastener at locations A, B and C. Check fit and make sure mud guard is parallel to ground before tightening. Install clips where shown.

