

FORD EDGE REAR MUD GUARD INSTALLATION INSTRUCTIONS

Please read instructions thoroughly before installation.

Tools Required

- Socket Wrench / Combination Wrench
- Drill Driver / 1/8" Drill bit

Package Contents

- Driver & passenger side rear mud guard
- Instruction sheet
- #10 SEM Screws (Qty 2)
- U-Clip (Qty 2)

NOTE: It may be necessary to remove the wheels depending on the tools used for installation.

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fastener from locations A and B.
3. Attach mud guard at locations A and B to fender with existing fasteners. Check fit and level before tightening.
4. Using the mud guard as a template drill an 1/8" hole through the fender liner at location C.
5. Install a #10 SEM screw through the mudguard, fender liner and into a supplied U-Clip on the backside of the fender liner at location C. **Note:** The U-clip does not clip over the fender liner; it goes on the backside of the fender liner and used as a nut.

