



Universal Installation Instructions

TOOLS REQUIRED:

- Corded or Cordless Drill
- 3/8" Socket Driver
- 1/4" Drill Bit (Optional)

KIT CONTAINS:

- 8 - Self-Tapping 1/4"x1" Screws
- 8 - Flat Washers
- Full or Cut Style Mud Flaps

IMPORTANT: The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws or bolts causing damage to vehicle or mud flaps

INSTALLATION:

1. Before you install your mud flaps, see the parts list for necessary parts
2. Square the flap with the tire while putting pressure against the wheel well, the outside edge of the flap should be 1/2" past the wheel well
3. Fasten the mud flaps into the metal lip of the wheel well with four washers and self-tapping screws.
(Tip: Start with the top screw, this will allow you to level the flap before installing the other screws.
You may also use a drill bit to make a pilot hole)
4. Repeat the procedure for remaining mud flaps

*Removing wheel may be necessary for installation

