

Installing the Bin Rail in Modular Shelves

These instructions cover installation of the H628 Bin Rail in modular shelves.

Tools Needed:

- Phillips head screwdriver
- 3/8" wrench



1. Line the holes on the bin rail up with the holes on the shelving tube. Slide the three screws, each with a black washer, through the bin rail and shelving tube to keep them together.



2. Put a black washer and a nut on each screw on the back end of the shelving tube and hand thread it on.



3. Tighten the nut using a 3/8" wrench and a Phillips screwdriver to hold the screw in place on the other side.