



# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

**TOOLS NEEDED:**  
5/16" Nut Driver

- 1 LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2 REMOVE THE 6 NUTS FROM THE GRILL STUDS AND THE 6 SCREWS THAT ATTACH THE GRILL SUPPORT FRAME TO THE HOOD USING A 5/16" NUT DRIVER
- 3 CAREFULLY LOWER THE HOOD AND SEPARATE THE GRILL FROM THE HOOD JUST ENOUGH SO THAT THE HOOD PROTECTOR WILL SLIDE BETWEEN THE GRILL AND THE HOOD.
- 4 WHEN THE HOOD PROTECTOR IS IN PLACE, CAREFULLY RAISE THE HOOD AND REINSTALL THE NUTS ON THE STUDS AND TIGHTEN. (DO NOT OVER TIGHTEN!) THEN REINSTALL THE SCREWS INTO THE GRILL SUPPORT FRAME.
- 5 LOWER AND LATCH THE HOOD AND CHECK TO MAKE SURE THE HOOD PROTECTOR IS FIRMLY IN PLACE AND CENTERED.

CLEANING YOUR HOOD PROTECTOR: USE ONLY WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR!

Stampede Automotive Products • Visit us at [stampedeproducts.com](http://stampedeproducts.com) • 800-241-7219

PRNTBFSTMP29 REV.A



# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

**TOOLS NEEDED:**  
5/16" Nut Driver

- 1 LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2 REMOVE THE 6 NUTS FROM THE GRILL STUDS AND THE 6 SCREWS THAT ATTACH THE GRILL SUPPORT FRAME TO THE HOOD USING A 5/16" NUT DRIVER
- 3 CAREFULLY LOWER THE HOOD AND SEPARATE THE GRILL FROM THE HOOD JUST ENOUGH SO THAT THE HOOD PROTECTOR WILL SLIDE BETWEEN THE GRILL AND THE HOOD.
- 4 WHEN THE HOOD PROTECTOR IS IN PLACE, CAREFULLY RAISE THE HOOD AND REINSTALL THE NUTS ON THE STUDS AND TIGHTEN. (DO NOT OVER TIGHTEN!) THEN REINSTALL THE SCREWS INTO THE GRILL SUPPORT FRAME.
- 5 LOWER AND LATCH THE HOOD AND CHECK TO MAKE SURE THE HOOD PROTECTOR IS FIRMLY IN PLACE AND CENTERED.

CLEANING YOUR HOOD PROTECTOR: USE ONLY WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR!

Stampede Automotive Products • Visit us at [stampedeproducts.com](http://stampedeproducts.com) • 800-241-7219

PRNTBFSTMP29 REV.A



# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

**TOOLS NEEDED:**  
5/16" Nut Driver

- 1 LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2 REMOVE THE 6 NUTS FROM THE GRILL STUDS AND THE 6 SCREWS THAT ATTACH THE GRILL SUPPORT FRAME TO THE HOOD USING A 5/16" NUT DRIVER
- 3 CAREFULLY LOWER THE HOOD AND SEPARATE THE GRILL FROM THE HOOD JUST ENOUGH SO THAT THE HOOD PROTECTOR WILL SLIDE BETWEEN THE GRILL AND THE HOOD.
- 4 WHEN THE HOOD PROTECTOR IS IN PLACE, CAREFULLY RAISE THE HOOD AND REINSTALL THE NUTS ON THE STUDS AND TIGHTEN. (DO NOT OVER TIGHTEN!) THEN REINSTALL THE SCREWS INTO THE GRILL SUPPORT FRAME.
- 5 LOWER AND LATCH THE HOOD AND CHECK TO MAKE SURE THE HOOD PROTECTOR IS FIRMLY IN PLACE AND CENTERED.

CLEANING YOUR HOOD PROTECTOR: USE ONLY WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR!

Stampede Automotive Products • Visit us at [stampedeproducts.com](http://stampedeproducts.com) • 800-241-7219