

# INSTALLATION INSTRUCTIONS

## **CUSTOMER SERVICE**

Phone: 866-900-8800 • 8:30 am - 5:00 pm Mon - Fri CST

Email: [info@undercoverinfo.com](mailto:info@undercoverinfo.com)



# MODEL SPECIFIC GUIDE

HIDDEN HINGE VERSION


2188

## Model 2188 Ford Ranger 5' Bed 2019-2023

**NOTE:** The bulkhead seals are installed without any drop-in bedliner in place. Install supplied Bulkhead Seals to the front bulkhead first, before installing truck mounting brackets and bed cover.


**NOTE:** If the truck is equipped with drop-in bed liner, trimming may be required to install the bulkhead seals and truck brackets supplied in hardware kit.

### Bulkhead Seal Installation:




**Install the bulkhead weather seal to the truck's front bulkhead. After installing the bulkhead seals proceed to mounting the truck specific brackets.**

**NOTE:** Rubber Filler Strip Installation- The hardware kit for this truck includes 8 rubber spacers. Verify location by holding each front bracket at its desired measurement location. Place a rubber filler strip at each clamp location by sliding the rubber filler strips upward in between the backside of the plastic bed cap and the metal bed rail lip until they bottom out. **See diagram A.** Make sure the clamps are adjusted all the way up against the metal bed rail lip while tightening the clamps for each bracket.



### RE: Step 2 on the Quick Start Guide


Measurement for the rear mounting bracket is 32 1/4" from the back side of the bulkhead to the front edge of the bracket.



### RE: Step 3 on the Quick Start Guide

Measurement for the front bracket is 18" from the back side of the bulkhead to the back side of the front bracket. Once cover is installed, the cover may need to be adjusted according to the gap at the tailgate. This can be done by loosening the clamps at the front only and adjusting the front brackets forward/backward.

The fit of the cover to the truck bed is determined by the front mounting brackets. This measurement is a good starting point. Unfortunately not all truck beds are assembled 100% square, so some adjustments may be necessary after the cover is set on the truck.






# MODEL SPECIFIC GUIDE HIDDEN HINGE VERSION

## Model 2188 Ford Ranger 5' Bed 2019-2023

Adjust the lock strikes up or down accordingly. With the tailgate down adjust the lock strike to allow approximately 1/8" (3mm) play in the cover up and down.

Torque to 8.5ft lbs or 100in lbs.

### PASSENGER SIDE



It may be necessary to adjust the latch side to side, to do so loosen the two latch mounting bolts, adjust latch and tighten.

Torque to 8.5ft lbs or 100in lbs.

### PASSENGER SIDE

