

INSTALLATION INSTRUCTIONS

CUSTOMER SERVICE

Phone: 866-900-8800 • 8:30 am - 5:00 pm Mon - Fri CST

Email: info@undercoverinfo.com




MODEL SPECIFIC GUIDE

HIDDEN HINGE VERSION

Model 4076 Toyota Tundra Std/Double Cab 6.5' Short Bed 2007-2013 (Will Fit W OR W/O Deckrail System)

Deck Rail System Hardware
8 - 1" Bolts
8 - Square Nut Plates




RE: Step 2 on the Quick Start Guide

If installing on truck with Deck Rail System follow instructions below.

If installing on truck without Deck Rail System skip to measurement charts on reverse side.

Remove the end caps from the Deck Rail System. Slide the tie down cleats towards the center of the Deck Rail. Slide the Square Nut Plates in place and position at rear of bed, install 1" bolts and washers according to diagram below and position the bracket according to the chart on reverse side.






MODEL SPECIFIC GUIDE HIDDEN HINGE VERSION

Model 4076 Toyota Tundra 6.5' Short Bed 2007-2013

Continued - RE: Step 2 on the Quick Start Guide

Measurement for the rear mounting bracket is 51" from the back side of the bulkhead to the front edge of the bracket.



RE: Step 3 on the Quick Start Guide

Measurement for the front bracket is 17" from the back side of the bulkhead to the end of the bracket.

The fit of the cover to the truck bed is determined by the front mounting brackets. This measurement is a good starting point. Unfortunately not all truck beds are assembled 100%, so some adjustments may be necessary after the cover is set on the truck.

