


**IMPORTANT:**

*Manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.*




### TOOLS REQUIRED



5/16 & 3/8" Open End  
Wrench & Socket Wrench


AND



Electric or Chargeable  
1/2" or 3/8" Drill




3/8" Socket Driver




1/4" Drill Bit

### FLAPS

(1) Flap Assembly,  
Front, DS




(1) Flap Assembly,  
Front, PS



### PARTS BAG # 766127

- a) (6) Washer, Flat  
0.203" x 1", SS  
Part #018081




- b) (2) Washer, Lock  
#10, Helicoil, SS  
Part #024001




- c) (2) Hex Nut  
#10, SS  
Part #025003



- d) (2) Screw, Machine  
#10 x 1.5"  
Part #012027





- e) (2) Washer, Half, SS  
0.203" x 1"  
Part #018032



# INSTALLATION *(For ease of installation it is suggested that the wheel be removed)*

1. Before you install your Gatorback Mud Flap, see the diagram and parts list for all necessary parts.
2. Remove two (2) factory screws #4 & #5. Using the two (2) factory screws and included washers #018081, reinstall on holes #1 & #2. Loosely secure at this point.
3. Square the flap with the tire, while putting pressure against the wheel well, then tighten the two (2) factory screws #4 & #5.
4. Hold flap tight against wheel well and drill a 1/4" hole (1), from the center of the slotted hole #3 through the factory plastic liner. Secure the flap with one (1) machine screw #012027, one (1) flat washer #018081, one (1) half washer #018032, one (1) lock washer #024001 and one (1) hex nut #025003.
5. Repeat procedure for passenger side.



Please check out our YouTube channel to see an install video for this application.

