

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Honda	Crosstour



## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S4 - Behind passenger side rear access panel

## CUSTOM WIRING HARNESS



## NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

- 10mm socket
- Ratchet
- Small, flat blade screwdriver

## **⚠ WARNING**

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

- Signal Circuits - 3.0 amps per side
- Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Access the vehicle wiring harness connector, located in the cargo area behind the passenger's side interior trim panel. See position S4, shown in the 'Wiring Location Guide'.

## Step 2

Locate the vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

## Step 3

Open the vehicle rear hatch and remove cargo area cover and cargo storage tray (A,B).

## Step 4

On the passenger side, remove the side cargo tray by removing the 10mm bolt holding it in place (C).

## Step 5

Remove the two fasteners and small center cover from the rear scuff panel. Remove rear scuff panel by pulling out on the bottom and then up (D).

## Step 6

Remove the 10mm bolt and cargo tie down from the passenger's side trim panel (E).

## Step 7

Pull out on the passenger side trim panel to locate the vehicle's white trailer tow connector. The tow connector will be similar to that on the towing wiring harness (F).

## Step 8

Insert the tow wiring harness housing into the vehicle trailer tow connector. Make sure that the housings are fully inserted with the locking tabs in place (G).

## Step 9

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape (H).

## Step 10

Locate the vehicle fuse box in the engine compartment, on the driver side, near the firewall. Remove the fuse panel cover and insert the provided 15 amp fuse into fuse position 10 (I). Check the vehicle owner's manual or contact the vehicle manufacturer for more information.

## Step 11

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

## Step 13

Reinstall all items removed during install and reconnect the negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

