


Components and Hardware:



Components and Hardware:



- | | |
|---|------|
| 1. Driver side step rail..... | (1) |
| 2. Passenger side step rail..... | (1) |
| 3. Front bracket..... | (2) |
| 4. Rear bracket..... | (4) |
| 5. M8-1.25 x 30mm flanged cap screw w/washer..... | (12) |
| 6. M10x12mm carriage bolt..... | (12) |
| 7. M10 flanged hex nut..... | (12) |

Tools for Installation:

- 12mm socket
- 14mm socket
- Ratchet wrench

INSTALL :

1. Install rocker panel brackets to the attachments points located on the backside of the channel using the supplied (#6) M10x12mm carriage bolts and (#7) M10 flanged nuts. Leave finger tight for now.



2. Remove any factory hardware and discard.
3. Beginning with the (#1) driver side, carefully raise the step rail up and match the brackets with the factory mounting locations. Next, starting with the center bracket and using the supplied (#5) M8X30mm Hex cap with washer, start and leave loose.
4. Start the remaining hardware with the front and rear bracket and leave loose.



5. Next, adjust the step assembly up/down and front/back to level out the step rail with body panel and then tighten step to brackets at 20 ft. /lbs
6. After final adjustment, torque each bolt (#5, #7) to 17ft/lbs - 20 ft/lbs.
7. Repeat steps 2-6 with (#2) passenger side.

